

# WALL MOUNT with DÉCOR ONLY INSTALL GUIDE

*Thank you for biting into our patent pending...*

## HF Hang Fangs dot com

3-D Photo Album 4-Corner Décor-Only  
or No Warp Wall Anchors

4 Frameless wAll aRt

*Make your wall art better today.*

*Hang with the best.*



Made in the U.S.A.

### ***Improve your LOVE of LIFE:***

- You'll love our *Photo Album Corner Décor and No Warp Wall Anchors*,
- **SOLD AS Décor-Only Mount** on **pre-hung Frameless Wall Art**, BUT...
- **Wall Mountable corners** can anchor (not included) for no warp or fall.
- **Heavy Duty: Fang 40 lbs.** with top slide-out or slide-up for easy removal.
- We bring **beauty, brains, and brawn** to your wall art and anchor method.
- Also adheres to *other pre-hung wall art* as framed, unframed, metal, etc.
- Enjoy our **DESIGNER FINISHED CORNERS** as a classy lifestyle brand.
- QUICK UPGRADES for artsy-fartsy, seasons, styles, or mood changes.
- *Be your own artist* creating unique **art-on-art** in your *Photo Album Finish!*
- With all **your favorite colors and textures** on **any wall at home or work.**

*Art frames cost \$150 and up. Hang Fangs wows your cheap and expensive wall art as fabulous, precious, and new in your own art show for the cost of a haircut.*

*Our wall mount fixes warps with décor only option to help hide them.*

# INSIDER SCOOP

*To hang or to fang...that is the question.*

## **CHOOSE HANG FANGS' SIZE BY WALL ART THICKNESS:**

**Small Hang Fangs' Size** for 3/4" to 1" thick frameless wall art.

**Medium Hang Fangs' Size** for 1" to 1 1/4" thick frameless wall art.

**Large Hang Fangs' Size** for 1 1/4" to 1 1/2" thick frameless wall art.

## **FRAMELESS WALL ART WALL MOUNT:**

4) Hang Fangs' Wall Mountable/Décor-Only Corner Frames.

15) Removable Double-Sided Tape Squares = 1" x 1" x .09".

1) This downloadable Wall Mount Install Guide.

## **RECOMMENDED WALL ANCHOR SUPPLIES (not included):**

4) 3" x 3" Adhesive Notes.

1) Level (preferably 1"-2" to mount to Corner Frames with our tape).

(**PRO TIP:** a helper makes any level length work).

1) Optional Ladder (depending upon height of top of wall art).

4) Drywall Wall: #8 Screws in Plastic Screw-In Drywall Anchors (best),

Concrete/Brick Wall: #8 Concrete Anchors or Screws (pre-drill).

Wood Wall: #8 or similar wood screws (pre-drill).

Smooth Wall: (metal, glass, etc.): Double-sided removable tape.

**DISCLAIMER:** Adhesives have the risk of taking off paint or art surfaces or other damage when removed incorrectly so we follow 3M's advice and recommendations in our guides at [hangfangs.com](http://hangfangs.com) to convey manufacturer use, recommendations, and resources with best use as we make no representations or warranties as to the accuracy, completeness, or reliability of adhesive specifications. We sell our products 'As Is' without any guarantees or warranties, express or implied with a 30-day money back guarantee. The user assumes all risks associated with the use of this product, as [hangfangs.com](http://hangfangs.com) disclaims all liability for any damage including direct, indirect, incidental, or consequential. We convey 3M knowledge, use, and removal techniques for 300LSE transfer tape 9472LE in conjunction with Hang Fangs ABS corner frames as a Medium Surface Energy (MSE) to other Low Surface Energy (LSE) surfaces such as painted canvas, unpainted canvas, fabric, and other art materials for proper use of 3M tape with our products.

# INSTALL

## TABLE OF CONTENTS

**WARP TEST:** 1-corner warp=Push 1 warped corner to wall with all others touching and if catty-corner pulls away it's a 2-corner warp (IIA); if more corners pull out or pushing both warps in and more corners pull out is a 3 or 4-corner warp (IIB). Hide warps with décor mounts **OR** fix with page 2 supplies.  
**SCENARIO:** 12) pieces with 1) 1-corner warp and 1) 3-corner warp.  
**SOLUTIONS:** 10) décor-only (IA), 1) 2 anchors (IIA), and 1) 4 anchors (IIB), **OR** 12) Corner décor warp cover-ups nano taped to pre-hung wall art (IA).  
**GOT WARP?** Section IIA1, page 6: **WARP FIX NOTE: ALL SURFACES.**

- I. A. **DÉCOR-ONLY MOUNT ON FRAMELESS WALL ART.**  
Nano tape to wall art corners for Warp Cover-Up, (easy, included).  
B. **QUICKLY REMOVE, REUSE, AND UPGRADE.** (Pages 4-5)
  
- II. A. **1-2 Warp Fix CATTY CORNER DRYWALL ANCHORS.**  
Page 2 has supplies: (safe, not included).  
B. **3-4 Warp Fix 4-CORNER DRYWALL ANCHORS (40 lbs.).**  
Page 2 has supplies. (safe, not included).  
*INSTALL A* for pre-hung art OR *INSTALL B* “No nail hole! Help?”  
C. **QUICKLY REMOVE, REUSE, AND UPGRADE.** (Pages 6-17)
  
- III. A. **DÉCOR-ONLY GLASS, CERAMIC, METAL, PLASTIC, ETC.**  
Removable Tape (not included)=**No Warp Fix**. Page 2 has supplies.  
B. **QUICKLY REMOVE, REUSE, AND UPGRADE.** (Pages 18-20)
  
- IV. A. **DÉCOR-ONLY OR SCREW FIX ON WOOD.**  
Nano Tape=**No Warp Fix** and #8 Screws (**Warp Fix**) not included.  
B. **QUICKLY REMOVE, REUSE, AND UPGRADE.** (Page 21)
  
- V. A. **DÉCOR-ONLY OR ANCHOR FIX ON BRICK/CONCRETE.**  
Nano Tape=**No Warp Fix**, Anchor Bolts (**Warp Fix**) not included.  
Page 2 has wall anchor supplies (décor-only included).  
B. **QUICKLY REMOVE, REUSE, AND UPGRADE.** (Page 22)

## SECTION I (pages 4-5)

### **I. DÉCOR-ONLY MOUNT ON FRAMELESS WALL ART.**

Nano tape to wall art corners for Warp Cover-Up, (easy, included).

1. **All frameless wall art is pre-hung first.** If your frameless wall art is pre-hung, proceed to #2. **PREP:** Have frameless wall art, wall hanger, and hammer ready. **STEP 1:** Hang your frameless wall art.
2. **Corner Décor Install on pre-hung wall art.** **PREP:** Have wall art pre-hung, 4 Hang Fangs' corners, and a ruler ready. **STEP 2:** Remove pre-hung wall art from the wall hanger and stand upright on a flat surface leaning against the wall. Place a Hang Fangs' corner fully on the lower-left corner of the art pushing it forward from behind against back of Hang Fangs' mount plate on back corner of art leaving a gap of 3/32" to 11/32" (a gap larger than 11/32" requires the next size down and less than 3/32" gap requires the next size up of Hang Fangs') between art front and the inside of the extended front of the Hang Fangs' corner. Measure the gap in 1/16" increments to determine how many nano tape shims are required in each corner (there's a built-in 1/32" gap for canvas folds). Repeat for all corners making a note of each shim count.
3. **Install Nano Tape Shims.** **PREP:** Have shim count for each corner. Lay all 4 Hang Fangs' corners on a flat surface as they are to be applied to wall art and have the sheet of double-sided nano tape squares ready. **STEP 3:** Peel the first square shim from the nano tape sheet and place it on the lower-left Hang Fangs' mount plate from the "Tape" line to the corner under the raised portion. Peel the top protective layer from each placed nano tape square before placing more shims on top and peel off final top layer for décor mount.
4. **Mount Hang Fangs' Corners and Hang Wall Art.** **PREP:** Have shimmed Hang Fangs ready to mount and wall art ready. **FINAL STEP 4:** Place lower-left Hang Fangs' corner SQUARELY AND FULLY on your wall art. You can pull, twist, and push to reposition the Hang Fangs' corner but once it's pressed on it's hard to adjust with light force. Once square, press the mount plate from behind the picture corner while also pressing from the front frame on the same corner next to the Hang Fangs' corner for 20 seconds for full adherence. Gap from art front to extended Hang Fangs' corner should be about 1/32" (canvas variances). **PRO TIP:** The first try with nano tape can require redoing to get used to the feel which is why there are extra nano tape shims. To try again if not square, hold wall art and grab offending Hang Fangs' corner to slowly twist downward easing it to the back of wall art as allowed until it releases

(remove errant nano tape from wall art and Hang Fangs' corner and repeat **STEPS 3-4** like a pro). Hang wall art and enjoy! **FINIS! Warps? I don't see any stinking warps. Do you?**

**B. QUICKLY REMOVE, REUSE, AND UPGRADE.**

1. **DÉCOR MOUNTED CORNER REMOVE/REPLACE**: Remove wall art from the wall and place on a flat surface lying face down. Grab the lower-left Hang Fangs' corner and slowly twist it off the corner to the back as allowed lifting art with other hand until the bond releases. Remove all nano taped Hang Fangs' corners and nano tape from them and wall art. **RECYCLE, REUSE OR UPGRADE**: Have a ruler, 4 new Hang Fangs' corners, and your wall art ready for **STEP 1** above. **DONE!**

## SECTION II (pages 6-17)

### A. 1-2 Warp Fix CATTY CORNER DRYWALL ANCHORS.

See page 2 for supplies. (safe, not included).

- 1. Warp Fix Note for All Surfaces.** 4-corner anchoring in **Section II B** is the strongest fix for warps but you can anchor two catty-corners (2 holes) for 1-2 warps...when you have a single warp, why fang all 4 corners? **Warps can be fixed using anchors in drywall (II), screws in wood (IV), and anchors in brick and concrete walls (V).** However, warped wall art pulling corners away from the wall is exactly how nano tape, pull tape, etc., are removed. **To fix minor warps on glass, ceramic, metal, plastic, etc. requires using multiple strips of removable pull tape or permanent double-sided tape as desired** (please see manufacturing specifications as many options exist; **III**). It's hardest to fix warps on smooth surfaces so enjoy décor-only Hang Fangs if you can **(I)** or use non-warped wall art. **PRO TIP:** 90% of frameless wall art is within 3/32" or 5/32" of standard sizing requiring 1 or 2 nano tape shims and 9% take 3 shims. 1% are non-standard frameless wall art and other art with no dimensional manufacturing requirements i.e., metal or framed wall art, using up to 5 shims (included). 1" and greater frames are less likely to warp but are more expensive to make, so less expensive art typically fits the 3/4" and 1" Hang Fangs' corners as most likely to have variances and warp. Hang Fangs to the rescue! All corners must be measured due to canvas variances (wood is to specification) which can be cut away if not folded flat. Return to **Table of Contents** or continue...
- 2. Pre-Hang for Catty-Corner 1-2 Warp Fix.** Now that you know which 2 catty-corners require anchors (holes) to fix your warp (**Warp Test** in **Table of Contents**), the other 2 catty-corners are **nano taped décor-only**. All catty-corner anchored frameless wall art is pre-hung first due to incomplete corner support allowing art to twist out of the Hang Fangs' corners. If your frameless wall art is pre-hung, proceed to #3. **PREP:** Have frameless wall art, wall hanger, and hammer ready. **STEP 1:** Hang frameless wall art.
- 3. Décor-Only Corner Measures.** **PREP:** Have wall art pre-hung, 2 Hang Fangs' corners, and a ruler ready. **STEP 2:** Remove pre-hung wall art and stand upright on a flat surface leaning on a wall. Place a Hang Fangs' corner fully on the **bottom non-anchored corner** (décor only) of wall art pushing it forward from back of Hang Fangs' mount plate leaving a gap of 3/32" to 1/32" (larger than 11/32" requires the next size down and less than 3/32"

requires the next size up of Hang Fangs) between art front and the inside of the extended front of the Hang Fangs' corner. Measure the gap in 1/16" increments to determine how many nano tape shims are required in each corner (there's a built-in 1/32" gap for canvas folds). **PRO-TIP:** measure picture starting solid against frame to Hang Fangs' corner vs. pushing picture in. Place the other Hang Fangs' corner on the **top non-anchored (décor only) corner catty-corner to the bottom non-anchored (décor only) corner** and repeat **STEP 2 noting shim counts for décor-only corners.**

4. **Install Nano Tape Shims for Décor-Only.** **PREP:** Have sheet of double-sided nano tape squares 3/4" x 3/4", shim counts, and 2) Hang Fangs' corners ready. **STEP 3:** Peel a square shim from the nano tape sheet and place it on the lower Hang Fangs' mount plate from the "Tape" line to the corner under the raised portion. Peel the protective top layer from each nano tape square shim as you place the proper count on Hang Fangs' corners.
5. **Mount Décor-only Shimmed Hang Fangs' Corners.** **PREP:** Have 2) shimmed Hang Fangs' corners and non-hanging wall art ready. **STEP 4:** Place both shimmed Hang Fangs' décor-only corners on top and bottom of non-anchored catty-corners of wall art **SQUARELY** before pressing on the back of the Hang Fangs' mount plate and the front frame of the wall art (NOT JUST ART) together for 20 seconds for full adhesion. **PRO-TIP:** it's easier to ensure square level fit of décor-only Hang Fangs' corners before pressing against back of wall art by twisting and tweaking. To try again if it won't stay square on your wall art, slowly twist the Hang Fangs' corner easing it towards the back of the art as allowed until it releases. Remove the tape from wall art and Hang Fangs' corners and repeat STEP 3 above like a pro. **Hang your wall art with two catty-corner décor-only Hang Fangs' corners mounted.** If you need square shims or paper covers, you can cut them to measure on Insider Scoop page.
6. **Measure To-Be-Anchored Corners for Shims.** **PREP:** Have wall art pre-hung, 2) Hang Fangs' corners, and a ruler ready. **STEP 5:** Remove wall art and place a Hang Fangs' corner on the **bottom non-anchored corner** of wall art pushing it forward against back of Hang Fangs' mount plate leaving a gap of 3/32" to 11/32" (larger than 11/32" requires the next size down and less than 3/32" requires the next size up of Hang Fangs) between art front and the inside front of the extended Hang Fangs' corner. Measure the gap in 1/16" increments to determine how many nano tape shims are required (there's a built-in 1/32" gap for canvas folds). Place other Hang Fangs' corner on **top non-anchored catty-corner and repeat STEP 5 for the top as well.**
7. **Install Nano Tape Shims in Two To-Be-Anchored Hang Fangs' Corners.** **PREP:** Have sheet of nano tape squares (treated as shims) 3/4" x 3/4", 2) Hang

Fangs' corners, corner shim counts, scissors, and 2) Square Paper Adhesive Blockers (template on page 23) ready. **STEP 6:** Peel a square shim from the nano tape sheet and place it on top of the lower Hang Fangs' mount plate from the raised "Tape" placement angle to the corner under the raised corner portion. Peel the protective top layer from each nano tape square shim and place the required shim count on both to-be-anchored corners in the same manner. Since both corners are anchored to the wall, we need to remove the adhesive surface from the top of both shim stacks by placing paper squares on the top adhesive surface. Cut out two squares from the templates on page 23 and place them on top of both nano tape shim stacks on the Hang Fangs' corners to be anchored. **PRO-TIP:** We don't want nano tape adhesive in addition to anchor bolts as that makes removal difficult. **Use either nano tape décor-only corners or drywall anchors but not both simultaneously. Nano taping top Hang Fangs' corners that slide on and off of an anchor makes removal of wall art really hard. DON'T USE BOTH ON THE SAME CORNER!**

8. **Placing 3" x 3" adhesive notes on Wall.** **PREP:** Have 2) 3" x 3" adhesive notes, pencil, and level (with nano tape square unless you have a helper) ready. **STEP 7:** Hang wall art on wall hanger. Place level on bottom of wall art. Hold bottom décor-only mounted Hang Fangs' corner to wall without moving and place a 3" x 3" adhesive note between the wall and wall art behind the opposite to-be-anchored bottom corner with  $\frac{3}{4}$ " edge of paper exposed out of the bottom and side of the wall art for corner tracing. Place the Hang Fangs' bottom corner to be anchored FULLY AND SQUARELY on bottom of wall art testing shim fit. Level again before you trace the Hang Fangs' corner side and bottom and set aside. Check for level and place second 3" x 3" adhesive note between wall and wall art on top catty-corner to the bottom corner to be anchored with note extending  $\frac{3}{4}$ " above and side of wall art so you can trace around the Hang Fangs' corner top and side. Place the Hang Fangs' top corner to be anchored FULLY AND SQUARELY on top of wall art (don't adhere adhesive shim on mount plate to wall art yet). Level before tracing the Hang Fangs' corner on top and side and set aside. Place wall art on a flat surface leaning against a wall. Leave traced notes on wall.
9. **Mark Hang Fangs' Corners on Wall.** **PREP:** Have a sheet of double-sided nano tape shims, 2) #8 Screws in Plastic Screw-In Drywall Anchors, Phillips screwdriver (drill is best), pencil, and 2) shimmed Hang Fangs' corners ready.

**STEP 8:** Place Hang Fangs' bottom corner to-be-anchored on the bottom 3" x 3" adhesive note stuck on the wall in the traced corner. Mark the center of the hole in the center of the mount plate with the pencil. **PRO-TIP:** the hole on the Hang Fangs' mount plate is for bottom mounting only while slide

channels are for upper mounting only. Set Hang Fangs' corner aside, poke a #8 screw through the marked hole on paper into the drywall and use screwdriver to go 1/8" deep. Repeat on the upper 3" x 3" adhesive note for above corners with slide-out (standard) or slide-up mount (around wall features but slides up higher to release). **For SLIDE-OUT TOP MOUNT (most common)**, make pilot hole centered at the end of the horizontal channel on the Hang Fangs' corner mount plate. **For SLIDE-UP TOP MOUNT (rare based on space)**, make pilot hole centered at the top end of the vertical channel on the side of the Hang Fangs' corner mount plate. Remove both adhesive notes from the wall.

10. **Fang Hang Fangs' Corners on Wall**. **PREP:** Have a sheet of double-sided nano tape shims, 2) #8 Screws in Plastic Screw-In Drywall Anchors, Phillips screwdriver (with drill is best), and 2) shimmed Hang Fangs' corners ready. **STEP 9:** Remove the screw from both plastic drywall anchors and screw both screw-in drywall anchors into the 1/8" deep holes you just made. Place the bottom Hang Fangs' corner with mount hole over the bottom screw-in drywall anchor hole and screw in the #8 screw snugly. On the top hole, screw in a #8 screw sticking out 1/8" from the wall to snugly hold mount plate allowing application and removal. Test fit by sliding the Hang Fangs' channel on to the 1/8" screw and snug it to barely slide on and off. Set upper Hang Fangs' corner to the side.
11. **Mount Wall Art on Wall**. **PREP:** Have wall art pre-hung and the upper Hang Fangs' corner ready. **FINAL STEP 10:** While hanging on the wall, place bottom-corner of hanging wall art in Hang Fangs' corner on the wall. **For slide-out mounting**, place upper Hang Fangs' corner to be anchored on the top corner of wall art 1 1/2" from the side of the art and slide along top to catch #8 screw mounted in the wall until it slides fully into the channel squarely on wall art. If you're using **slide-up mounts**, then place the upper Hang Fangs' corner on the upper corner of wall art against side 1 1/2" above it, sliding down the side until the Hang Fangs' channel catches the #8 screw fully and squarely to fix your 1-2 catty-corner warp(s). **FINIS!**

**B. 3-4 Warp Fix 4-CORNER DRYWALL ANCHORS (40 lbs.).**

See page 2 for supplies. (safe, not included).

INSTALL A for pre-hung and INSTALL B “No nail hole! Help?”

1. **INSTALL A: PRE-HUNG WALL ART AS THE LONE HANGER. (easy)** **All frameless wall art is pre-hung first; makes nail and 4 anchor holes.** If your frameless wall art is pre-hung, proceed to #2. **PREP:** Have frameless wall art, hanger, and hammer ready. **STEP 1:** Hang wall art.
2. **Measure Corners.** **PREP:** Have wall art, 4) Hang Fangs’ corners, pencil, scratch paper, and a ruler ready. **STEP 1:** Remove pre-hung wall art and set on a flat surface against a wall. Place a Hang Fangs’ corner on **bottom-left corner** of wall art pushing it forward from behind against back of Hang Fangs’ mount plate leaving a gap of 3/32” to 11/32” (larger than 11/32” requires the next size down and less than 3/32” requires the next size up of Hang Fangs) between art front and the inside front of the extended Hang Fangs’ corner. Measure the gap in 1/16” increments to determine how many nano tape shims are required (there’s a built-in 1/32” gap for canvas folds). Place other Hang Fangs’ corners on **lower-right and top corners** and repeat **STEP 1** on each noting shim counts for each corner for next steps.
3. **Install Nano Tape Shims in Hang Fangs’ Corners.** **PREP:** Have the sheet of nano tape square shims 3/4” x 3/4”, 4 Hang Fangs’ corners, corner shim counts, scissors, and square paper adhesive blocker (templates on page 23 ready). **STEP 2:** Peel a square shim from the nano tape sheet and place it on the lower Hang Fangs’ mount plates from the raised “Tape” angle on top of the mount plate to the corner under the raised corner portion. Peel the protective top layer from each nano tape square shim and place the required shim count on all four Hang Fangs’ corners. Since these are to be anchored to the wall, we remove the adhesive surface from the top of the shim stacks by placing paper on top. Cut four squares from the templates on page 23 to place on top of four nano tape shim stacks on the Hang Fangs’ corners to be anchored. **PRO-TIP:** Nano tape adhesion and anchor bolts together make art removal extremely difficult, especially for top mounts that **slide off and on**. **Use either nano taped décor-only corners OR drywall anchors, but not on the same corner.**
4. **Fang First Hang Fangs’ Corner.** **PREP:** Have Phillips screwdriver (best with drill), 1) #8 screw with plastic screw-in drywall anchor, lower-left shimmed Hang Fangs’ corner, a 3” x 3” adhesive note, level, and pencil (best) ready. **STEP 4:** Level pre-hung wall art with level on bottom before placing

a 3” x 3” adhesive note between wall and wall art with 3/4” paper sticking out from behind art on the bottom and left edges. Place the shimmed lower-left

corner FULLY AND SQUARELY on hanging wall art corner, level again, and trace around the Hang Fangs' corner on the bottom and left side with pencil. Remove Hang Fangs' corner and wall art and set aside. Place the Hang Fangs' corner on the traced lines on the 3" x 3" adhesive note and mark the center of the hole in the mount plate in pencil. Using a #8 screw, make a 1/8" deep pilot hole into the center of the hole marked on the adhesive note on the wall. Remove adhesive note from wall and screw the screw-in drywall anchor in hole. Place lower-left Hang Fangs' mount plate hole over the drywall anchor hole and screw in #8 screw snug and square.

5. **Fang Second Hang Fangs' Corner. PREP:** Have wall art, shimmed lower-right Hang Fangs' corner, drill, 1) #8 screw with plastic screw-in drywall anchor, a 3" x 3" adhesive note, level, nano tape square from sheet, and pencil ready. Remove protective plastic from both sides of the nano tape square and stick it to the bottom of the lower-right Hang Fangs' corner. **STEP 5:** Hang wall art and place lower left corner in the Hang Fangs' corner stirrup on the wall. Level before placing adhesive note between the wall and wall art sticking out from behind art 3/4" on the lower-right corner bottom and right sides. Level again and trace around the corner on the bottom and right side. Remove wall art, Hang Fangs' corner, nano tape, and level and set aside. Place the lower-right Hang Fangs' corner on the traced lines on the adhesive note as it will hang and mark the center of the hole in the mount plate in pencil. Screw a #8 screw into the center of the hole marked on the adhesive note on the wall 1/8" deep for a pilot hole. Remove adhesive note from wall and screw in screw-in drywall anchor. Place lower-left Hang Fangs' corner mount hole over drywall anchor hole, and screw in #8 screw snug and square.
6. **Remove Wall Art Hanger. PREP:** Have hammer with a claw or pliers ready to yank the pre-hung nail. We want the top slide-out (or slide-up) Hang Fangs' corners to release the wall art from here on. **STEP 6:** Remove wall art pre-hung hanger (nail); patch and paint the hole or hide behind wall art for now.
7. **Place 3" x 3" Adhesive Notes on Wall and Trace. PREP:** Have wall art, 3" x 3" Adhesive Notes, 2) Hang Fangs' corners, pencil, ladder if needed, and level (nano tape) ready. **STEP 7:** Lift wall art flat against the wall dropping evenly into both mounted Hang Fangs' bottom corners, turn as needed. Place an adhesive note on the upper-left corner behind wall art on the wall with 3/4" paper sticking out on the left and upper sides for tracing. Place upper-left shimmed Hang Fangs' corner FULLY AND SQUARELY on wall art corner

and trace around the left and upper sides and set corner aside. While continuing to hold wall art flat against the wall, move to the upper-right corner and place an adhesive note on the upper-right corner behind wall art on the wall with 3/4" paper sticking out on the right and upper sides for tracing.

**PRO-TIP:** You may be best removing wall art, move yourself [and ladder] to the other side, and reinstall wall art in bottom Hang Fangs' corners so you're not fighting wall art in switching sides. It's not a race. Place the upper-right shimmed Hang Fangs' corner FULLY AND SQUARELY on wall art corner and trace around the right and upper sides and set aside. Set wall art aside leaving two traced adhesive notes on the wall.

8. **Mark Two Upper Hang Fangs' Corners.** **PREP:** Have 2) upper Hang Fangs' corners, ladder, and pencil. **STEP 8:** You need to decide if the top Hang Fangs' corners are **SLIDE-OUT TOP MOUNT (most common)** or **SLIDE-UP TOP MOUNT (rare based on space as they slide even higher than art to remove).** For Slide-Out Top Mounts, place upper-left shimmed Hang Fangs' corner on the traced corner on the left adhesive note on the wall and mark the center of the end of the horizontal slide-in channel hole (for Slide-Up Top Mounts this would be the top-end of the vertical slide-in channel) and set aside. Repeat marking hole for upper-right Hang Fangs' corner after placing it on the traced corner on the adhesive note on the right.
9. **Fang 2 Upper Hang Fangs' Corners and Mount Wall Art.** **PREP:** Have wall art, Phillips screwdriver, 2) upper Hang Fangs' corners, ladder, and 2) #8 screws with screw-in drywall anchors ready. **STEP 9:** Make a 1/8" deep pilot hole in both mount hole markings on the wall and remove the adhesive notes. Screw in both plastic screw-in drywall anchors with #8 screws sticking out 1/8" to fit the Hang Fangs' mount plates. Test both for snug fit. Mount wall art in both lower Hang Fangs corners (turn if needed) and (climb ladder with the upper-left Hang Fangs' corner in hand) and install Hang Fangs' corner 1 1/2" to the left of wall art on top sliding until it catches the #8 screw FULLY AND SQUARELY. Remove wall art, move ladder, and reinstall wall art in bottom Hang Fangs' corners pushing wall art to the wall with the upper-right Hang Fangs' corner in hand. Install the upper-right Hang Fangs' corner 1 1/2" to the right of wall art on top sliding left until it catches the #8 screw and slide in (or down) FULLY AND SQUARELY. **FINIS!**

1. **INSTALL B: LONE HANGER/HELP.** “*No nail hole! Help?*” (harder). **NOTE:** INSTALL A (IIB1 above) makes frameless wall art pre-hung (recommended) for The Lone Hanger but makes a nail hole and 4 anchor holes; INSTALL B makes just 4 anchor holes but you hold the art = harder. **Wall Art and 3” x 3” Adhesive Note Placement.** **PREP:** Have 4) Hang Fangs’ corners, 4) 3” x 3” adhesive notes, pencil, and level with nano tape square ready. **STEP 1** Decide where you’re going to hang your wall art and place a 3” x 3” adhesive note on wall in lower-left corner with ¾” sticking out below and to the left side of the wall art corner so you can trace around the side and bottom. Place Hang Fangs’ lower-left corner on the adhesive note on the wall ¾” from the left and bottom paper edge and trace around the bottom and left edge of the Hang Fangs’ corner. **Ensure picture location now.** **Mark the center of the hole in pencil** through the mount plate on adhesive note and set aside.
2. **Measure Hang Fangs’ Corners for Shims.** **PREP:** Have wall art, 4) Hang Fangs’ corners, pencil, scratch paper, and a ruler ready. **STEP 2:** Remove pre-hung wall art setting on a flat surface against a wall. Place a Hang Fangs’ corner on **bottom-left corner** of wall art pushing it forward from behind against back of Hang Fangs’ mount plate leaving a gap of 3/32” to 11/32” (larger than 11/32” requires the next size down and less than 3/32” requires the next size up of Hang Fangs) between art front and the inside front of the extended Hang Fangs’ corner. Measure the gap in 1/16” increments to determine how many nano tape shims are required (there’s a built-in 1/32” gap for canvas folds). Place other Hang Fangs’ corners on **bottom and top corners** and repeat **STEP 1** on each noting corner shim counts for next steps.
3. **Install Nano Tape Shims in Hang Fangs’ Corners.** **PREP:** Have the sheet of nano tape square shims ¾” x ¾”, 4) Hang Fangs’ corners, corner shim counts, scissors, and 4) Square Paper Adhesive Blockers (template on page 23) ready. **STEP 3:** Peel a square shim from the nano tape sheet and place it on the lower Hang Fangs’ mount plates from the “Tape” line to the corner under the raised portion. Peel the protective top layer from each nano tape square shim and place the required shim count on all four Hang Fangs’ corners. Since these are to be anchored to the wall, we need to remove the adhesive surface from the top of the shim stacks by placing paper squares on top. Cut out four squares from the templates on page 23 cutting squares to place them on top of both nano tape shim stacks on the Hang Fangs’ corners to be anchored. (set 4<sup>th</sup> square paper adhesive blocker aside), **on all EXCEPT the lower-right Hang Fangs’ corner which needs to remain adhesive**

**during the wall marking stage.** Then, we’ll place the remaining non-adhesive paper square on the shim stack to turn it into a non-adhesive shim

prior to anchoring. **WARNING:** Nano tape adhesion and anchor bolts together make art removal extremely difficult, especially for top mounts that are supposed to **slide off and on** anchor bolts. Use either **nano taped décor-only corners** OR **drywall anchors** on each corner, but **NOT BOTH ON ONE CORNER.**

4. **Fang First Hang Fangs' Lower-Left Corner.** **PREP:** Have Phillips screwdriver (best with drill), 1) #8 screw with plastic screw-in drywall anchor, and lower-left shimmed Hang Fangs' corner ready. **STEP 4:** Screw in a #8 screw into the center of the hole marked on the adhesive note on the wall 1/8" deep pilot hole. Remove adhesive note, screw the plastic screw-in drywall anchor in wall, and place lower-left Hang Fangs' corner mount hole over drywall anchor hole, screw in #8 screw snug and square.
5. **Temporarily Nano Tape Lower-Right Corner to Wall Art.** **PREP:** Have wall art and lower-right shimmed corner with exposed adhesive ready. **STEP 5:** Mount the lower-right Hang Fangs' corner **FULLY AND SQUARELY** on the wall art lower-right corner. Push on the back of the Hang Fangs' mount behind wall art for two seconds for temporary adherence for wall marking. Press from front over frame, **NOT JUST ART.** Pressing longer is harder to remove but stays on better as needed for tracing.
6. **Mark Second Hang Fangs' Lower-Right Corner.** **PREP:** Have wall art, level, pencil, screwdriver, 3" x 3" adhesive note, and 1) #8 screw with plastic screw-in drywall anchor ready. It's best to have supplies within reach of your right hand on a chair or step ladder below the right corner of wall art that you can reach while holding with your left hand, especially for The Lone Hanger. **STEP 6:** Pick up wall art with left hand under the middle of the bottom frame and your right hand on the middle of the right-side frame pushing wall art **flat against the wall** sliding the lower-left corner into the lower-left Hang Fangs' corner mounted on the wall. **Be careful, especially The Lone Hanger, don't let wall art fall forward while mounted in a single Hang Fangs' bottom corner. If wall art falls forward, lift out of bottom corner mount. Especially for 3' x 3' or larger wall art. Make slow deliberate moves for ideal results and get help if needed.** No falling art allowed! Holding wall art against the wall, take your left hand from the bottom frame and put it on the right frame above your right hand which you can now release... **keep wall art flat against wall AND in Hang Fangs' lower-left corner stirrup!** Then, use your right hand to get a 3" x 3" adhesive note and place it on the wall

between wall art and wall with the bottom and right sides both sticking out 3/4" from behind wall art. Use your level on bottom of wall art to ensure you're holding it level and then **use your pencil to mark around the corner side and bottom of the lower-right Hang Fangs' corner temporarily adhered**

to the wall art. REMOVE CORNER: Keeping wall art flat against the wall, put your right hand back on the right wall art frame beneath your left hand and put your left hand back on the bottom frame in the middle to lift wall art out of the lower-left Hang Fangs' corner and set aside. Test the lower-right Hang Fangs' corner placement marks lifting wall art flat against the wall in the lower-left Hang Fangs' corner stirrup and use your level to verify. THIS MUST BE ACCURATE. Move adhesive note as needed leaving 3/4" exposed from under the wall art location on the bottom and right sides. **PRO-TIP: Especially for the Lone Hanger:** when using one hand to hold art always be prepared to use your free hand to stabilize it. Have a set down plan never letting wall art to fall forward or leverage you awkwardly when in a Hang Fangs' corner stirrup. Get help when needed.

7. **Remove Temporarily Nano Taped Lower-Right Hang Fangs' Corner.** **PREP:** Have wall art with temporarily nano taped lower-right corner on a flat surface leaning on a wall. **STEP 7:** Hold wall art on the right-side frame with your left hand 10" above the lower-right corner and grip the Hang Fangs' corner with your right hand from the front and rear of the wall art and twist it downward and to the back of the art when able until it releases. Hopefully, the nano tape shims didn't get removed from the Hang Fangs' corner or messed up requiring you to shim it again with more nano tape squares. Either way, you need to put the left-over square paper on the top of the final shim stack to stop adherence before anchoring to the wall. **PRO-TIP: NEVER use nano tape adherence AND anchor bolts together on a single corner.**
8. **Fang Second Hang Fangs' Lower-Right Corner.** **PREP:** Have shimmed lower-right Hang Fangs' corner, pencil, wall art, screwdriver, and #8 screw and plastic screw-in drywall anchor ready. **STEP 8:** Place lower-right Hang Fangs' corner on the adhesive note on the wall in the drawn lines and mark the center of the hole in pencil in the Hang Fangs' mount plate and set aside. Use the screwdriver and #8 screw to twist a pilot hole 1/8" deep before removing the adhesive note from the wall. Screw in the plastic screw-in drywall anchor. Then, hold the Hang Fangs' mount plate HOLE over the drywall anchor hole and screw in the #8 screw snugly. Test fit wall art flat against the wall in both mounted Hang Fangs bottom corners, remove, and set aside. Corners may need turning to allow wall art to slide in.
9. **Place 3" x 3" Adhesive Notes on Wall and Trace.** **PREP:** Have wall art, 3" x 3" Adhesive Notes, 2) Hang Fangs' corners, pencil, ladder if needed, and level with nano tape squares ready. **STEP 7:** Lift wall art flat against the wall dropping evenly into both mounted Hang Fangs' bottom corners. They may require turning out so wall art can slide in. Then, place an adhesive note on

the upper-left corner behind wall art on the wall with 3/4" paper sticking out on the left and upper sides for tracing. Place upper-left shimmed Hang Fangs' corner FULLY AND SQUARELY on wall art corner and trace around the left and upper sides and set corner aside. While continuing to hold wall art flat against the wall, move to the upper-right corner and place an adhesive note on the upper-right corner behind wall art on the wall with 3/4" paper sticking out on the right and upper sides for tracing. **PRO-TIP:** You may be best removing wall art, move yourself [and ladder] to the other side, and reinstall wall art in bottom Hang Fangs' corners so you're not fighting wall art in switching sides. It's not a race. Place the upper-right shimmed Hang Fangs' corner FULLY AND SQUARELY on wall art corner and trace around the right and upper sides and set aside. Set wall art aside leaving two traced adhesive notes on the wall.

10. **Mark Two Upper Hang Fangs' Corners.** **PREP:** Have 2) upper Hang Fangs' corners, ladder as needed, and pencil. **STEP 8:** You need to decide if the top Hang Fangs' corners are **SLIDE-OUT TOP MOUNT (most common)** or **SLIDE-UP TOP MOUNT (rare based on space as they slide even higher than art to remove)**. For Slide-Out Top Mounts, place upper-left shimmed Hang Fangs' corner on the traced corner on the left adhesive note on the wall and mark the center of the end of the horizontal slide-in channel hole (for Slide-Up Top Mounts this would be the top-end of the vertical slide-in channel) for a #8 screw in the Hang Fangs' mount plate and set aside. Repeat for the upper-right shimmed Hang Fangs' corner placing it on the traced corner on the adhesive note on the right. For Slide-Out Top Mounts, mark the center of the end of the horizontal slide-in channel hole (for Slide-Up Top Mounts this would be the top-end of the vertical slide-in channel) for a #8 screw and set aside.
11. **Fang 2 Upper Hang Fangs' Corners and Mount Wall Art.** **PREP:** Have wall art, screwdriver, 2) upper Hang Fangs' corners, ladder as needed, and 2) #8 screws with screw-in drywall anchors ready. **STEP 9:** Make a 1/8" deep pilot hole in both mount hole markings on the wall and remove the adhesive notes. Screw in both plastic screw-in drywall anchors with #8 screws sticking out 1/8" to fit the Hang Fangs' mount plates. Test both for snug fit. Mount

wall art in both lower Hang Fangs corners (turn if needed) and (climb ladder with the upper-left Hang Fangs' corner in hand) push wall art to the wall and install Hang Fangs' corner 1 1/2" to the left of wall art on top sliding until it catches the #8 screw FULLY AND SQUARELY. Remove wall art, move ladder, reinstall wall art in bottom Hang Fangs' corners pushing wall art to the wall with the upper-right Hang Fangs' corner in hand. Install the upper-

right Hang Fangs' corner 1 ½" to the right of wall art on top sliding left until it catches the #8 screw and slide on FULLY AND SQUARELY. **FINIS!**

### C. QUICKLY REMOVE, REUSE, AND UPGRADE.

1. **DÉCOR MOUNTED CORNER REMOVE/REPLACE:** Remove wall art from the wall and place on a flat surface lying face down. Grab the lower-left Hang Fangs' corner and slowly twist it off the corner to the back as allowed lifting art with other hand until the bond releases. Remove all nano taped Hang Fangs' corners and nano tape from them and wall art. **RECYCLE, REUSE, OR UPGRADE:** Have a ruler, 4) new Hang Fangs' corners, and your wall art ready for **STEP 1** above. **DONE!**
2. **DRYWALL ANCHOR INSTALLED CORNER REMOVE/REPLACE:** Remove two top Hang Fangs' corners first by sliding the upper-left Hang Fangs' corner to the left 2" to remove and then slide the upper-right Hang Fangs' corner to the right 2" to remove (or slide them both up 2" to remove for Slide-Up Mounts). Set wall art aside. With a Phillips screwdriver (with a drill is best) unscrew both lower Hang Fangs' corners from the anchors and remove nano tape from them and the wall art. **RECYCLE, REUSE, OR UPGRADE:** Have a ruler, 4 new Hang Fangs' corners and your wall art ready for **STEP I** above. Alternatively, complete removal without reusing requires unscrewing screwed in anchors to paint and patch. If removing the wall art as well then patch and paint the nail hole e.g., hanger hole, too. **DONE!**  
**WARNING: Never let wall art fall forward when only mounted on bottom mounts only as excessive leverage may cause damage; lift out of Hang Fangs' corners after removing top Hang Fangs' corners.**

### SECTION III (pages 18-20)

#### A. DÉCOR ONLY GLASS, CERAMIC, METAL, PLASTIC, ETC.

Removable Tape (not included)=**No Warp Fix**. Page 2 has supplies.

1. **NOTE:** Due to numerous nano tapes, pull tapes, and other new technologies, we only include enough double-sided nano tape for Hang Fangs' décor-only installs to adhere corners to wall art, shims for Hang Fangs' corners on wall art, adhering level to Hang Fangs' corners, and adhering adhesive notes to brick and concrete, and extra squares for do overs. We can't provide specifications for the vast selection of removable tapes or not for attaching your art piece to a smooth wall. We'll walk you through the install with your double-sided nano tape roll (some people put it on the back of art frames in addition to Hang Fangs' corners outside our use for extra load support, but we leave this choice up to you and the nano tape specifications for cantilevered loads). **WARNING: Never put nano tape on the front or sides of wall art as it may remove paint.**
2. **Determine Hang Fangs Load Area for Nano or Pull Tape.** Warped corners pull in the same manner required to remove nano tape from walls, so it's not recommended to hang warped wall art on smooth surfaces. **STEP 1:** To determine load, measure square inch area on the back of two lower Hang Fangs' corners as this will support the entire art load as the top two mounts merely hold art steady and parallel. Consider placing more tape on the back of art frames if needed for heavier wall art and check manufacturing load specifications by area. Compare this to the nano tape specifications for possible loads. To increase the support load to hold your wall art may require long nano tape strips on the back of your wall art frame at the top, sides, and/or bottom. The Hang Fangs' mount is 1/8" thick and nano tape is 1/16" thick so using Hang Fangs' corners means putting nano tape strips on art frames would have to be tripled to match the layer of tape and the Hang Fangs' mount itself i.e., three strips 6" long on top of each other on each side. No matter which method you use, measure wall art in Hang Fangs' corners for required nano tape shim counts for all four corners and insert as follows.
3. **Measure Corners.** **PREP:** Have wall art, 4) Hang Fangs' corners, pencil, scratch paper, and a ruler ready. **STEP 1:** Remove pre-hung and set wall art on a flat surface leaning against a wall. Place a Hang Fangs' corner on **bottom-left corner** of wall art pushing it forward from behind against back of Hang Fangs' mount plate leaving a gap of 3/32" to 11/32" (larger than

11/32" requires the next size down and less than 3/32" requires the next size up of Hang Fangs) between art front and the inside front of the extended Hang

Fangs' corner. Measure the gap in 1/16" increments to determine how many nano tape shims are required (there's a built-in 1/32" gap for canvas folds). Place other Hang Fangs' corners on **lower-right and top corners** and repeat **STEP 1** on each noting shim counts for next steps and specific corner placing.

4. **Install Nano Tape Shims in Hang Fangs' Corners.** **PREP:** Have the sheet of square nano tape shims 3/4" x 3/4", 4) Hang Fangs' corners, corner shim counts, scissors, and 4) Square Paper Adhesive Blockers (template on page 23) ready. **STEP 2:** Peel a square shim from the nano tape sheet and place it on the lower Hang Fangs' mount plates from the "Tape" line to the corner under the raised portion. Peel the protective top layer from each nano tape square shim and place the required shim count on all four Hang Fangs' corners. Since these are to be anchored to the wall, we need to remove the adhesive surface from the top of the shim stacks by placing paper on the top. Cut out four squares from the templates on page 23 cutting squares to place them on top of all four nano tape shim stacks on the Hang Fangs' corners to be anchored.
5. **Mount Hang Fangs' Corners as Décor-Only to Reduce Tape Usage.** You can tape the wall art using the frame method above without taping the Hang Fangs' mount plates and install them as décor-only mounts in Section I. This saves not only the tape on four Hang Fangs' corners but one strip of nano tape on each side of the wall art as you're no longer matching the corner strips i.e., two strips 6" long on top of each other on each side (see tape manufacturing specifications) vs. three strips and taping all four corners in #2 above.
6. **You Can Nano Tape 4 Hang Fangs' Corners ONLY for Lightweight Art.** This method avoids putting tape on the back wall art frame. **PREP:** Have double-sided nano tape roll (not included), pull tape (not included), permanent tape (not included), or glue technology (not included), scissors, and wall art ready with all four Hang Fangs' corners. **STEP 1:** Apply sticking method to the back of all four Hang Fangs' mounts with protective backing in place. **PRO-TIP:** When using pull tape, be sure to leave pull tabs accessible on top of all 4 Hang Fangs' corner mounts for later release (bottom Hang Fangs' corner pull tabs will be hidden behind wall art whilst top Hang Fangs' corner pull tabs will be hidden above wall art but accessible while wall art is mounted). Lay all four Hang Fangs' corners on a flat surface on the wall mount plate in the positions they'll hang on the wall. Locate the lower-left Hang Fangs' corner, remove backing and place squarely

on the smooth wall where you want your picture location using non-adhered level and press Hang Fangs' corner/art to wall for 20 seconds to fully mount.

7. **Mount Second Hang Fangs' Lower Right Corner.** **PREP:** Have a nano tape square, level, and lower right Hang Fangs' corner ready. Use a nano tape

square to adhere level (**included**) to bottom of lower-right corner as it would hang on the wall. **STEP 2:** Attach level to the bottom of the lower-right Hang Fangs' corner holder using a nano tape square. Remove nano tape backing from the lower-right Hang Fangs' corner and place **FULLY AND SQUARELY** on lower-right corner of wall art as you mount art in the lower-left Hang Fang's corner on the wall. Press level corner against the wall for 20 seconds. Set wall art aside.

8. **Mount Both Upper Hang Fangs' Corners.** **PREP:** Have 2) upper Hang Fangs' corners, and wall art ready. **STEP 3:** Lift wall art into both bottom mounted Hang Fangs' corner stirrups with wall art flat against the wall. Peel protective backing off top-left Hang Fangs' corner and place **FULLY AND SQUARELY** on the top-left corner of the wall art and press against the wall for only a couple seconds. Move to the upper-right corner with the upper-right Hang Fangs' corner and remove the protective backing. Place it on the art **FULLY AND SQUARELY** and press the corner against the wall for 20 seconds. Go back to the upper-left corner and push it against the wall for 20 seconds as well. There isn't a slide function on top Hang Fangs' corners on smooth surfaces due to being taped so you'll have to remove following nano tape specifications requiring slow peeling and twisting away from the wall if necessary down the road. **FINIS!**

## **B. QUICKLY REMOVE, REUSE, AND UPGRADE.**

1. Follow bonding method removal instructions which nano tape typically says twist and pull slowly and continuously with increasing force until nano tape begins to peel from all surfaces. Pull from the top and sides of each Hang Fangs' corner and give them a twist slowly pulling towards the back as allowed until they come off. Remove nano tape or other bond from wall, wall art, and Hang Fang's corners. **RECYCLE, REUSE OR UPGRADE:** Have a ruler, 4 new Hang Fangs' corners, and your wall art ready for **STEP 1** above. **DONE!**

## SECTION IV (page 21)

### **A. DÉCOR-ONLY OR SCREW FIX ON WOOD.**

Nano Tape=**No Warp Fix** and #8 Screws (**Warp Fix**) not included.

1. **PREP:** Drywall and wood wall installation is very similar except that drywall uses anchor bolts while wood uses #8 screws (best for warps) and tapes like pull, nano, double-sided permanent, etc. (no warp fix). **Don't use nails on Hang Fangs' corners.** Just like drywall, if you pre-hang your wall art on wood, you can do Section I Frameless Wall Art Corner Décor only mounts which is easiest. A difference is when you're tasked with making a 1/8" starter hole through the adhesive note for a #8 screw, use a 1/8" wood drill bit in hardwood and 3/32" wood drill bit in softwood (not included). The other main difference is drywall uses anchors in the Hang Fangs' mount plates while the best for wood is to use four screws (not included) for all four corners for warps and secure mounting. Please have Phillips screwdriver on drill, 4) #8 screws (not included), 1/8" wood drill bit (on hardwood but not softwood as no pilot hole), and ladder ready. If you choose to nano tape the bottom Hang Fangs' corners only, please see Section III above on possible tape uses.
2. **STEP:** Below are the applicable sections for wood wall mounting, so assemble your own using our specs.

### **SECTION I:**

#### **A. FRAMELESS WALL ART Corner DÉCOR & WALL MOUNT.**

Nano tape décor/warp cover-ups (easy, cheap). *FINIS!*

### **SECTION II:**

#### **A. 1-2 Warp Fix CATTY CORNER DRYWALL ANCHORS.**

#### **B. 3-4 Warp Fix CORNER DRYWALL ANCHORS (40 lbs.).**

INSTALL A for pre-hung and INSTALL B "No nail hole! Help?"

*FINIS!*

#### **B. QUICKLY REMOVE, REUSE, AND UPGRADE.**

1. Adapt the drywall removal directions to wood walls as applicable. **DONE!**

## SECTION V (page 22)

### **A. DÉCOR-ONLY OR ANCHOR FIX ON BRICK AND CONCRETE.**

Nano Tape=**No Warp Fix**, Anchor Bolts (**Warp Fix**) not included.

Page 2 has wall anchor supplies (décor-only included).

1. **PREP:** Drywall, brick, and concrete use anchor bolts and similar directions. Just like drywall, if you pre-hang your wall art on brick or concrete, you can do Section I Frameless Wall Art Corner Décor only mounts which is easiest. One difference to keep in mind as you adapt drywall anchor mounts to brick and concrete anchor mounts is that 3" x 3" adhesive notes won't stick well without nano tape. Therefore, when instructed to use 3" x 3" adhesive notes please also use a nano tape square removing protective plastic from both sides and stick on the brick/concrete first then adhere adhesive note. A second difference is when you're tasked with making a 1/8" pilot hole through the adhesive note, use a 1/8" masonry bit and 1/2" hammer drill (not included). Concrete screws also work in pilot holes in concrete and brick while nano tape claims to work as well (see vast solutions and specifications).
2. **STEP:** Below are the applicable sections for Brick and Concrete mounts. Assemble using our specs and your favorite concrete/brick anchor.

### **SECTION I:**

#### **B. FRAMELESS WALL ART Corner DÉCOR & WALL MOUNT.**

Nano taped décor/warp cover-ups (easy, cheap). *FINIS!*

### **SECTION II:**

#### **C. 1-2 Warp Fix CATTY CORNER DRYWALL ANCHORS.**

#### **D. 3-4 Warp Fix CORNER DRYWALL ANCHORS (40 lbs.).**

INSTALL A for pre-hung and INSTALL B "No nail hole! Help?"

*FINIS!*

### **C. QUICKLY REMOVE, REUSE, AND UPGRADE.**

1. Adapt the drywall removal directions to concrete/brick as applicable. **DONE!**

LAST CHANCE...

Buy today before your favorite colors and textures run out.

*“They got them dang Hang Fang thangs, honey!”*

[www.hangfangs.com](http://www.hangfangs.com)

*We're fly on the wall.*

